



Modular One Piece Grip – Removal & Installation

Grip removal: Before performing these steps, field strip the pistol by following the instructions in Section 8.1 of the Owners Manual

Action	Picture
<p>1. Insert the disassembly tool in the magazine well.</p>	
<p>2. Rotate the disassembly tool a quarter turn.</p> <p>3. At the same time remove the grip plate from the rear of the frame.</p>	

Grip installation:

Action	Picture
<ol style="list-style-type: none"> 1. Install the grip plate from the rear by sliding it forward until it snaps securely in place. 2. Use caution to ensure the trigger bar and decocking lever springs are not dislodged during grip plate installation. 	

After installation: Reassemble the pistol by following the instructions in Section 8.4 of the Owners Manual.

Perform a Function Verification by following the steps in Section 8.6 of the Owners Manual Section

If you have any questions regarding the correct removal or installation of the Modular One Piece Grip, please contact Customer Service at (603) 772-2302