

SIG SAUER® ELECTRO-OPTICS

ZULU6™ IMAGE STABILIZED BINOCULAR

QUICK REFERENCE GUIDE

INSTRUCTIONS:

INSTALLING BATTERIES:

The ZULU6 HDX PRO line of binoculars have two battery ports, located on the right and left side of the bottom of the binocular (14x50, 16x50, & 18x50) Unscrew the battery port cover and insert the battery with the positive (+) side facing outwards. Tighten the battery port cover until it is finger tight.

POWER ON/OFF:

Turn ON the image stabilization of your ZULU6 binoculars by toggling the power switch forward. A green power indicator light will light up when the power is ON.

OMNISCAN™:

The ZULU6 HDX PRO Binoculars feature the next generation of Optical Image Stabilization (OIS) now with proprietary OmniScan™ technology. OmniScan™ OIS optimizes image stabilization using a digital accelerometer to automatically detect movement and vibration to calibrate the level of image stabilization required for unmatched optical performance. Scan for game and seamlessly lock on targets with OmniScan™ OIS by Sig Sauer Electro-Optics.

AUTO SHUT OFF FEATURE:

The ZULU6 features an automatic shut off feature to help conserve battery life. The binoculars will automatically shut off 10 minutes after being turned ON. To reset the timer simply toggle the power switch.

INTERPUPILLARY DISTANCE OF BINOCULARS:

Set the distance between the centers of the right and left ocular lenses of the binoculars to match the distance between your left and right eyes. The field of view of the binoculars will be clear when your interpupillary distance is set correctly.

DIOPTER ADJUSTMENT:

View an object about 100 yards away from you. Close your right eye and adjust the focus wheel of the binoculars until the image is clear and sharp. Next, while looking at the same object, close your left eye and adjust the diopter adjustment ring on the right ocular lens until the image is clear and sharp.

FOCUS ADJUSTMENT:

The focus wheel is on the front of the ZULU6 binoculars above the objective lenses. Rotate the focus wheel clockwise to focus on objects closer.

EYECUP ADJUSTMENT:

SIG SAUER ZULU6 binoculars feature eyecups you can twist up and down to accommodate the eye relief distance required when wearing eyeglasses.

The logo for SIG SAUER, featuring the word "SIG" in a bold, italicized sans-serif font, followed by "SAUER" in a bold, italicized sans-serif font with a registered trademark symbol.

Download user manuals at
sigsauger.com/owners-manuals/