

SIG AIR[®]

AIRGUN/AIRSOFT MINI REFLEX SIGHT MANUAL

(2) Mount plates for use with:

M17 ProForce / M17 Pellet Gun / M18 ProForce



WARNING

READ MANUAL FULLY BEFORE USE.

Before installing the SIGAIR Mini Reflex Sight to your Air Pistol, always ensure that the Air Pistol is unloaded with the safety on.




WARNING: CANCER AND REPRODUCTIVE HARM—www.P65warning.ca.gov

TABLE OF CONTENTS

1.0 PRODUCT DESCRIPTION	2
2.0 FEATURES	2
3.0 BATTERY INSTALLATION	2
4.0 MOUNTING	3
5.0 WINDAGE and ELEVATION ADJUSTMENT	3
6.0 MAINTENANCE	3
7.0 REPAIRS/RETURNS/WARRANTY	4

PRODUCT DESCRIPTION

The SIGAIR Reflex Sight includes: lens cover, adjustment tools, battery, lens cloth, 2 mount plates (AIRGUN/AIRSOFT) and operating instructions.



- 1. Connection Screws
- 2. Objective Lens
- 3. Power Button
- 4. Battery (underbelly)
- 5. Windage adjustment
- 6. Elevation adjustment
- 7. Locking Screws (rear)
- 8. Sight screws (not shown)

FEATURES

- 6 Power Settings (OFF thru 5 reticle brightness options)
- 3 MOA Dot
- Wide Field of View
- Low Power Consumption
- Lightweight
- Shockproof
- Parallax corrected for precision accuracy
- Low Profile
- 1x23mm
- Water resistant

BATTERY INSTALLATION



1. Turn optic body upside down and insert the CR2032 battery with the positive (+) side showing.
2. Attach appropriate plate to base of sight with connection screws (1) until hand tight. Make sure sight is placed in correct direction so that the reflex lens is facing the muzzle.
3. Hold optic and plate together then flip optic side up and screw the connection screws (1) until firmly fixed.

WARNING: NEVER ATTEMPT TO MOUNT AN OPTIC ONTO A LOADED GUN.

Optic must be secured to selected mount plate before installing to slide.

MOUNTING

1. Remove slide from Air Pistol (refer to Air Pistol manual for instructions).
2. Place slide top side down on hard surface and remove the rear sight screws. Mount plate will now be removable-take off and store in safe place.
3. Optic and corresponding plate should already be secured to one another through Battery installation step (3.0) **Flip slide right side up** and align optic/plate atop slide being sure front of reflex lens is facing the muzzle.
4. Press plate against slide with one hand and flip slide upside down. With other hand, Reinstall the rear sight screws and tighten until snug.



TURNING SIGHT ON AND OFF

1. Turn the sight on by momentarily pressing the power button (3) on front of sight
2. To turn the sight off, press and hold the power button for 2 seconds. The sight will remain off until you momentarily press the power button selector. When the sight is turned back on, it will return to the last brightness level used.
3. To adjust the brightness level, with the sight turned on, momentarily press the power button to scroll through the brightness settings until you reach the desired brightness level.

WARNING: Adjustment to the windage and elevation screws without loosening the locking screws (7) may lead to damage to the unit.

WINDAGE AND ELEVATION ADJUSTMENT

1. Before any windage and elevation adjustments is made, loosen the locking screws (7) on the back of the unit.
2. Elevation adjustments – the elevation adjustments are on the top of the sight. To raise your point of impact, with the provided screwdriver, turn the

adjustment counter-clockwise. Each mark is equal to approximately 1 MOA. To lower the point of impact turn the adjustment clockwise.

3. Windage adjustments – the windage adjustments are on the right side of the sight. To move your point of impact to the left, with the provided screwdriver, turn the adjustment clockwise. Each index mark is equal to approximately 1 MOA. To move the point of impact to the right turn the adjustment counter-clockwise.

4. Tighten the locking screws to lock in the adjustment.

MAINTENANCE AND STORAGE

1. When cleaning lens, be sure to blow dirt/debris off of optic first. Wipe lens clean with a lens cleaning cloth. Remove any dirt or debris from unit with dry or damp cloth.

2. Before storing, make sure the optic is securely tightened to the air pistol/rifle (remove rifle) and be sure the optic is turned off.

3. If optic is going to be stored for an extended period of time it is a good suggestion to remove battery from unit in order to retain battery life.

REPAIR/RETURN/WARRANTY

If you have questions concerning the performance or servicing of your product, please write or call:

SIG SAUER, Inc.
Attention: Customer Service
18 Industrial Drive, Exeter, NH 03833
Phone: (603) 610-3000 ext. 1
Fax: (603) 766-7002

IF YOU DO NOT UNDERSTAND THE INSTRUCTIONS FOR OPERATING YOUR SIGAIR PRODUCT, IT IS YOUR RESPONSIBILITY TO CALL OUR CUSTOMER SERVICE DEPARTMENT AT (603) 610-3000 EXT. 1 BEFORE USING YOUR REFLEX SIGHT.

In the event that you need to return your SIGAIR Product to the SIG SAUER Service Department, here's what to do:

1. Contact Customer Service at (603) 610-3000 ext. 1 for a return merchandise authorization (RMA) number, which will allow SIG SAUER to track the status of your return from its receipt at SIG SAUER through its return to you. Please do not send your product until you obtain an RMA number.
2. Package the product securely to prevent damage. Enclose a letter that includes your name, street address, daytime phone number, model and serial number, and a detailed description of the problem you have experienced or the work that you want performed.

3. SIG SAUER is not responsible for any product until it is received, nor for damage incurred during shipment.
4. Be sure to write your RMA number on the package and Ship your Reflex Sight insured and prepaid (we do not accept collect shipments) to:

SIG SAUER, Inc.
Attention: Service Department
18 Industrial Drive Exeter, NH 03833

SIG SAUER® SIXTY (60) DAY LIMITED WARRANTY

Applies to U.S. Domestic Sales Only.

For International Sales please contact your local dealer/distributor.

SIG SAUER warrants that the enclosed SIGAIR product was originally manufactured free of defects in material, workmanship and mechanical function. For the period of , SIG SAUER agrees to correct any defect in the SIGAIR product for the original purchaser by repair, adjustment or replacement, at SIG SAUER's option, with the same or comparable quality components provided, however, that the SIGAIR product is returned unloaded and freight prepaid to SIG SAUER at 18 Industrial Drive, Exeter, NH 03833. Proof of purchase will be required with any request for warranty repair. This 60-day warranty is null and void if the SIGAIR product has been misused, damaged (by accident or otherwise fired with improper ammunition, fired with an obstruction in the barrel, damaged through failure to provide reasonable and necessary maintenance as described in the manual accompanying the product, or if unauthorized repair or any alteration, including of a cosmetic nature, has been performed on the product. This 60-day warranty does not apply to normal wear and tear of any parts. Subject to the foregoing, this 60-day warranty confers the right to have the covered SIGAIR product or its parts repaired, adjusted or replaced exclusively upon the original purchaser, which right is not transferable to any other person. This warranty is only valid for SIGAIR product purchased in the United States. IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, TO THE EXTENT APPLICABLE, SHALL BE LIMITED IN DURATION TO THE APPLICABLE PERIOD OF WARRANTY SET FORTH ON THIS PAGE. THE PURCHASER'S ONLY REMEDIES IN CONNECTION OF THE BREACH OR PERFORMANCE OF ANY WARRANTY ON SIG SAUER ARE THOSE SET FORTH ON THIS PAGE. IN NO EVENT WILL SIG SAUER OR ANY COMPANY AFFILIATED WITH SIG SAUER BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusions may not apply to you. This warranty give specific legal rights, and you may also have the rights which vary from state to state.



sigsauer.com

**SIG SAUER, Inc.
72 Pease Boulevard, Newington, NH 03801
USA**

All trademarks, service marks, trade names, trade dress, product names and logos appearing in this manual are the property of their respective owners. No trademark or service mark appearing in this manual may be used without written consent of the mark's owner.

©2018 SIG SAUER, Inc. All rights reserved. AN ISO 9001
REGISTERED COMPANY P/N 5700735-20 REV 00