

ZULU-DMR™

CARBON FIBER TRIPOD KIT

OPERATOR'S MANUAL

SIG SAUER

**TABLE OF CONTENTS**

INTRODUCTION	3
CONTENTS	4
KEY FEATURES	5
PRODUCT IDENTIFICATION	6
DUAL TENSION BALL HEAD SETUP	7
BALL HEAD SET UP	8
ADJUSTING LEG ANGLES	12
ADJUSTING LEG SECTION LENGTH	13
SPECIFICATIONS	14
SIG SAUER® INFINITE GUARANTEE™	16

INTRODUCTION

Engineered to the same specifications and standards as SIG SAUER's modern weapons systems, the ZULU-DMR™ Carbon Tripod was designed for intensive shooting, competition, and glassing performance. SIG SAUER's custom carbon fiber provides ultimate rigidity in load positions to eliminate flex and maintain accuracy in the most extreme environments, while the ARCA-Swiss compatible ball head ensures precision and adjustability, shot after shot. Rigorously tested from mountainsides to matches, the ZULU-DMR Carbon Tripod is a steadfast component for those that demand the best.

**CONTENTS**

- ZULU-DMR™ Carbon Tripod
- Carry Case
- ARCA-SWISS Base Plate
- 5 mm Allen Wrench
- 2.5 mm Allen Wrench


**KEY FEATURES**

- 52mm Dual Tension Ball Head
- ARCA-SWISS Compatible
- 3 Section Carbon Fiber Legs, with Vented Tubes
- 3 Position Detent Tabs for Adjusting the Angle of the Tripod Legs
- Rubber Over Molded Twist Locks




PRODUCT IDENTIFICATION

- A. 52mm Dual Tension Ball Head
- B. ARCA-SWISS compatible
- C. 3-Section Carbon Fiber Legs, with vented tubes
- D. 3 Position Detent Tabs, for adjusting the angle of the tripod legs
- E. Rubber Over Molded Twist Locks



DUAL TENSION BALL HEAD SETUP

1. **Ball Locking Knob** – Large diameter locking knob is designed for comfort and easy locking of the Ball Head
2. **Drag Knob** – Use this knob to add tension on the ball head to prevent your optics from dropping when the Main Locking Knob is loosened.
3. **Pan Knob** – Loosen the Pan Knob to allow for panning left and right, tighten Pan Knob to lock the Ball Head from rotating left and right.
4. **Quick-Release Locking Knob** – Using the included ARCA-Swiss base plate or your optics ARCA-Swiss base plate apply tension to the Locking Knob to apply tension. Loosen knob to remove your optic.







BALL HEAD SET UP

Installing the Ball Head properly prevents the Ball Head from loosening while in use.


1. Tighten the Pan Knob by rotating it closewise until tight.



2. Rotate the Ball Head counterclockwise to remove the Ball Head from the tripod base.



3. Using the included 2.5mm Allen key, loosen (counterclockwise) the three set screws on the tripod base.



4. Remove the Ball Head base plate by holding the mounting screw and pulling upward,.






5. Attach the Ball Head to the base plate by aligning the ball head and mounting screw and rotating the Ball Head (clockwise) to secure it to the base plate.



6. Locate the three set screws on the bottom of the Ball Head base plate, using the provided 2.5mm Allen Key hand tighten (clockwise) the three screws.



7. Lower the base plate and ball head onto the tripod stand. Using the included 2.5mm Allen key, hand tighten (clockwise) the three set screws on the tripod base.






ADJUSTING LEG ANGLES

Each of the legs have a leg angle pivot lock.


1. Pull the Leg Angle Pivot Lock from the front or push it from the rear to release the lock.
2. Adjust the legs to the desired Angle Stop.
3. Push the Leg Angle Pivot Lock back in the desired position and pull the leg out to engage the Angle Stop.



ADJUSTING LEG SECTION LENGTH

Each of the three-tripod leg sections can be extended to adjust the tripods height.

1. Twist the Leg Lock (counterclockwise) to loosen the tension.
2. Slide the leg section out to the desired length and twist the Leg Lock (clockwise) to lock in place.



**SPECIFICATIONS**

PRODUCT DETAILS	
SKU#	SOZT1002
MAX LOAD	55 lbs.
MIN. HEIGHT	30 in.
MAX. HEIGHT	69 in.
FOLDED DIMENSIONS (HXW)	31 in. x 5.9 in.
LEG MATERIAL	CARBON FIBER
LEG SECTIONS	THREE SECTION CARBON FIBER LEGS, WITH VENTED TUBES
LEG POSITIONS	3
LEG LOCKS	THREE POSITION DETENT TABS FOR ADJUSTING THE ANGLE OF THE TRIPOD LEGS
BALL HEAD MOUNTING INTERFACE	ARCA-SWISS
WEIGHT	6.44 lbs. WITH BALL HEAD

MEASUREMENTS	IMPERIAL	METRIC
OVERALL LENGTH	30 in.	762 mm
OVERALL HEIGHT	69 in.	1752.6 mm
OVERALL WIDTH	5.06 in.	128.72 mm
WEIGHT	103.07 oz.	2921.98 oz



SIG SAUER® INFINITE GUARANTEE™



SIG SAUER® has a history of quality and reliability that dates back more than 250 years. We understand the importance of true dependability whether it be in the line of duty, at the shooting range or on your next hunt and we continually strive to deliver products that meet and exceed the expectations of even the most demanding customers. That's why SIG SAUER is proud to offer our INFINITE GUARANTEE* on all our firearms, optics, and suppressors.

Our promise: We warrant that your new SIG SAUER firearm, optic, or suppressor was originally manufactured free of defects in material, workmanship, electrical, optical, and mechanical function. We will repair your SIG SAUER product in the event it becomes damaged or is defective in any way, at no charge to you. If we cannot repair your product, we will replace it or, if we cannot replace it, we will provide you with a replacement of equal value. All with no questions asked, forever.

SIG SAUER® Infinite Guarantee

- Fully Transferable
- No Warranty Card Required
- No Receipt Required
- No Time Limit Applies
- No Charge

Please note that our Infinite Guarantee excludes coverage for intentional damage, misuse, cosmetic damage that does not affect the performance of the optic, loss, theft, or unauthorized repair or modification. Excludes Tritium components.

Customers seeking warranty coverage must first obtain a Return Merchandise Authorization (RMA) by contacting SIG SAUER Customer Service and return the product unloaded and freight prepaid.

ANY WARRANTIES IMPLIED BY LAW, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSLY LIMITED IN DURATION TO THE DURATION OF THIS WRITTEN WARRANTY PERIOD. REPAIR, ALTERATION, OR REPLACEMENT AS PROVIDED HEREIN IS YOUR EXCLUSIVE REMEDY FOR ANY DEFECTIVE PRODUCT. IN NO EVENT SHALL SIG SAUER OR ANY COMPANY AFFILIATED WITH SIG SAUER BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY KIND ARISING OUT OF THE PURCHASE OR USE OF THIS PRODUCT, WHETHER BASED UPON CONTRACT, TORT, STATUTE, OR OTHERWISE.

Some states do not allow the limitation of implied warranties, or the exclusion or limitation of incidental or consequential damages, so some or all of the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from State to State.

This warranty applies to commercial customers only and does not apply to government, non-commercial, or non-US customers. Non-US COMMERCIAL CUSTOMERS MUST PURCHASE PRODUCT THROUGH AN AUTHORIZED SIG SAUER DEALER WITHIN THEIR COUNTRY OF RESIDENCE FOR THIS WARRANTY TO APPLY.

SIG SAUER®

sigsauer.com

FOR PRODUCT SERVICE ON THIS MODEL, PLEASE CALL 603-610-3000

12100 SW Tualatin Rd, Tualatin, OR 97062

All trademarks, service marks, trade names, trade dress, product names and logos appearing in this manual are the property of their respective owners.
No trademark or service mark appearing in this manual may be used without written consent of the mark's owner.